



JVD UV Disinfection Box

Product Codes: 388 101

Ultra-Violet Light Sterilization Box



Kills 99.9% of germs, viruses and bacteria with ultra-violet rays



Model: 3 88 101



Disinfect personal belongings like masks, phones and watches.



Charges phone via wireless charging or USB cable during sterilization process



Sterilization period varies from 5/10/15 minutes for various items




UV Sterilization Box



Specification

Input: DC 5V 2A
 Power: 2W
 Sterilization Power: 1W
 UV Wave Length: 254nm
 Wireless Charging: 5W
 USB Output: 5V/1A

Operating Temperature: -50°C to 104°C
 Outer Dimensions: 219/127/45mm
 Inner Dimensions: 178/98/25mm
 Net Weight: 300g
 Material: ABS+ PMMA
 3 Duration Modes - 5/10/15mins

How to Use

1. Attach USB cable to the port on the right side of the box and connect the other end to the power supply
2. Open the lid and place your belongings into it e.g. fabric masks, phones, jewellery etc.
3. You have the option to wireless charge your mobile phone or charge it by USB with or without the sterilization process.
4. Press Button Once to activate a 5 minute sterilisation period for metal products like watches and jewellery. The Button will flash Red light until sterilization is completed.
5. Press Button Twice to activate a 10 minute sterilisation period for electronic items such as mobile phones. The Button will flash Green light until sterilization is completed.
6. Press Button Thrice to activate a 15 minute sterilisation period for personal care items like masks and toothbrush. The Button will flash Blue light until sterilization is completed

NOTE

- + Light around the button will stop flashing after sterilization cycle is completed
- + You can open the lid and take out the objects in the middle of the sterilization cycle
- + UV light inside the unit will stop illuminating as soon as the lid is opened
- + Do not pour any liquid or hazardous material inside the box while in use.

For more information about this great product:



HARLE
 PHILIPPINES
 An ISO 9001:2015 Certified Company



Unit 408 SEDCCO1 Building, Rada corner Legazpi Streets, Legazpi Village, Makati City
 Tel. Nos.: (632) 8-892-8989 / (632) 8-553-8988 * Fax No.: (632) 8-892-1688
 E-mail: sales@harlephils.com Web: www.harlephils.com